




Plan View



Perspective View



 = 1 sq foot

General Setup Instructions


- Read entire setup instruction manual prior to unpacking parts and pieces.
- The setup instructions are created specifically for this configuration.
- Setup instructions are laid out sequentially in steps, including exploded views with detailed explanation for assembly.

Cleaning & Packing


- For Cleaning Metal, Plex, & Laminate Parts: Use a **MILD NON-ABRASIVE** cleanser and soft cloth/paper towel to clean all surfaces.
- Keep exhibit components away from heat and prolonged sun exposure.
Heat and UV exposure will warp and fade components.
- Retain all provided Packing Materials. All provided packing materials are for ease of repacking & component protection.

Disassembly


- For loss prevention, tighten all setscrews and locks during disassembly




Hex Tool - Essential for Assembly




Part Identification - Numbering




Spline Connection



Base Plate & Extrusion Connection



Extrusion & Lock Connection



Engaged Lock



WARNING



DO NOT USE POWER TOOLS




LADDERS OR LIFTS
MAY BE REQUIRED



ALL CONNECTIONS MUST
BE TIGHTLY SECURED


Top View of Each Level



Item	Qty.	Description
1	2	Base Plate
2A/2B	1/1	42" Vertical Extrusion
3A/3B	1/1	42" Vertical Extrusion
4A/4B	1/1	45" Horizontal Extrusion
5A/5B	1/1	45" Horizontal Extrusion
6A/6B	1/1	2.5" Angle-Cut Vertical

- Steps:
- 1) Attach base plates [1] verticals [2A] & [3A], using bolts.
 - 2) Connect verticals [2A] [2B] and [3A] [3B], using connection bars [B].
See **Straight Connection with Knobs** detail.
 - 3) Connect horizontals [4A] [4B] and [5A] [5B], using connection bars [A].
See **Straight Connection with Knobs** detail.
 - 4) Connect assemblies [2A/2B] and [3A,3B] with assemblies [4A,4B] and [5A,5B].
See **Corner Connection with Knob** detail.
 - 5) Connect angled verticals [6A] to [2B] and [6B] to [3B].
See **2.5" Angle-Cut Vertical Attachment** detail.
 - 6) Attach graphic to Velcro on back of assembled Backwall.


*** Corner Connection with Knob**



Turn knob clockwise to tighten lock.



Do not over tighten Knobs

☆ Straight Connection with Knobs




Slide connection bar between extrusions, then turn knobs clockwise to tighten lock.

Do not over tighten Knobs



Completed Backwall Front View



Steps:

- 1) Connect lights to top horizontals [5A/5B]. See **Light Connection** detail.
- 2) Attach **header frame assembly** [7/8/9] to top horizontals [5A/5B].
- 3) Attach **counter support assembly** [10/11] to Vertical [2A].
- 4) Attach shelf between [10] and [2A].
- 5) Attach support leg [10A] to curved extrusion [10].
- 6) Attach flange plate [11A] to top of Curved Extrusion [10].
- 7) Attach counter top to [11A]. See **Counter Top Attachment** detail.
- 8) Attach wings to A10 clamps. See **A10 Clamp** detail.
- 9) Attach monitor mount to vertical [2B]. See **Monitor Mount** detail.
- 10) Attach graphic to vertical [3B]. See **Graphic Attachment** detail.

Item	Qty.	Description
7/8/9	1	Header Frame Assembly
10/11	1	Counter Support Assembly
10A	1	Support Leg
11A	1	Flange Plate

